



ご質問がございましたら SEA EAGLE, Japan (日本正規代理店) までメールでご連絡下さい。
<https://www.seaeagle.jp/en/contact-us>

Explorer 300x/380x/420x

この度は SEA EAGLE の高品質インフレーターカヤックをお買い上げ頂き誠にありがとうございます。

組み立て・収納方法:

1. オレンジ色のリペアキットからバルブアダプターを取り出し、ポンプホースに装着してください。
2. カヤックを広げる。バルブキャップを外して下さい。バルブシステム（バルブ軸）を押しながら左へ 1/4 バルブシステムが立ち上がるまで回して下さい。
3. バルブ開口部にバルブアダプターを差し込み右に回して固定して下さい。
4. まずサイドのエアチューブに 2/3 まで空気を注入してください。ボートフロアが調整しやすくなります。
5. フロアを 2/3 膨らませてください。空気が均一になるように調整してエアチューブの下にくるようにしてください。
6. ボートフロアとエアチューブを完全に膨らませてください。目安としてはシワが伸び堅く感じられる程度です。
7. 全てのバルブキャップを閉じてください。
8. Deluxe Kayak Seat (DKS) (デラックス カヤックシート) を膨らませるために白いバルブが必要です。リングをバルブベースに付けて、バルブベースにバルブを取付けて下さい。トリプルバルブアダプターのうねのある端をポンプホースに挿入し、シワが伸び堅くなるまで空気を入れてください。
9. パドル: シャフトの端にドロップガードを挿入し、3つの穴が中央にくるようにシャフトを組み立ててください。
10. ドレインバルブ: 船体底面にドレインバルブ（水抜き穴）が装備されています。静水で使う場合は閉じてください。クラス 3 以上の急流または、海上で使用する場合はフロアドレインバルブを開けてご使用ください。
11. カヤックの収納: バルブキャップを取り外し、バルブシステムを押しながら 1/4 右へ回すとバルブシステムの弁が下がり空気が素早く出てきます。バルブの方へカヤックを折り畳みながら空気を抜いてください。スケグベースを曲げないように注意してください。フロアはカヤック内に入れたままで大丈夫です。十分に乾燥させてから収納してください。
12. シートの空気を抜きます。バルブを回しながら緩めてください。

ご使用上の注意:

- 作動圧力: エアチューブ 3.2 PSI (22 kPa) / ドロップステッチフロア 3.2~4 PSI (22~27 kPa) / Deluxe Kayak Seat (DKS) (デラックス カヤックシート) 1 PSI (7 kPa)
- SEA EAGLE 推奨のポンプを使用してください。市販のエアコンプレッサーは絶対に使用しないでください。(CO₂ または空気)
- 現地の河川・海上航行ルール、その他、規制・規則・法律を順守しましょう。
- ボート、カヤックに乗る際は必ずライフジャケットを着用しましょう。
- 絶対に子どもだけで SEA EAGLE ボート・カヤックを使用しないでください。
- 飲酒または薬を服用した後はカヤックを操縦しないでください。操船中にアルコールを摂取しないでください。
- 砂利や岩場の上などで SEA EAGLE ボート・カヤックを引きずらないようにしてください。可能であれば持ち上げて運んで下さい。
- ボートの最大積載量、定員を超えて乗船しないでください。最大積載量はボート内側に記載しています。
- 1人でカヤック、ボーティングに行かないでください。特にキャンプ、海旅や急流下りをする場合。
- 本製品は救命具ではありません。SEA EAGLE ボート・カヤックを絶対に救命具として使用しないで下さい。
- 水上に行く時は、常に誰かに何処に誰と行くか帰宅の予定は何時になるかを伝えて下さい。
- 全ての ボート・カヤックはメーカーの欠陥に対する 3年間の保証があります（詳しくはオンラインでご確認ください。）

SEA EAGLE 製品をご利用になる前に www.seaeagle.jp/ja/se/cat/5-Instructions で取扱説明ビデオをご覧ください。



Questions: Email Customer Service at <https://www.seaeagle.jp/en/contact-us>

Explorer 300x/380x/420x

Thank you for your purchase of our high quality inflatable kayak.

Basic Inflation Instructions:

1. Take the valve adapter from the orange repair kit and attach it to pump hose.
2. Roll out kayak. Remove valve caps. Press and turn the valve stem a ¼ turn to the left until it pops up.
3. Insert valve adapter into valve opening, turn right to lock in place.
4. Inflate the pontoon sides to 2/3 full so floor can be adjusted.
5. Inflate floor 2/3 full and adjust it so that it's even and under the side pontoons.
6. Fully inflate the floor and side pontoons until pumping becomes difficult (Pontoons & floor should be firm and wrinkle-free)
7. Close valve caps after inflating the kayak.
8. For DKS inflatable seat, locate the white valves. Attach the ring to the base then screw the valve in the valve base. Insert the ribbed end of the triple valve adapter in the pump hose. Pump until firm and wrinkle-free.
9. Paddle assembly: Insert the drip guard on the end of the paddle shaft. Assemble shaft with the three holes in the middle.
10. Close floor drains on flat-water. Keep drains open in whitewater above class 3 or ocean surf.
11. Deflate kayak by removing valve cap, push stem down and turn stem right until it stays down. Fold kayak toward valves. Skeg base must be kept flat. Floor can stay in kayak. Wipe dry before storing.
12. Deflate seats by unscrewing the valves.

Other Points:

- Working pressure of the pontoons: 3.2 PSI / Drop Stitch Floor: 3.2~4 PSI / DK Seats: 1 PSI
- Only use Sea Eagle recommended pumps and NEVER an air compressor (CO2 or air)
- Be aware of local boating rules and regulations and abide by them accordingly.
- Always wear a life jacket when on the water.
- DO NOT allow children to use Sea Eagle boats unsupervised.
- DO NOT consume alcohol while boating or operating a boat while under the influence of alcohol or drugs.
- DO NOT drag your Sea Eagle boat over rocks or gravel if it can be avoided.
- DO NOT exceed the certified maximum weight capacities of this boat – see capacity label on the inside of kayak.
- DO NOT go boating alone, especially if camping, exploring or going down a white water river.
- DO NOT use your Sea Eagle Boat as a personal flotation device as they are not designed for that use.
- Always let someone know where you are going and when you plan to return.
- All Sea Eagle boats have a limited 3 year Warranty against manufacturer's defects (more detail online)

Make sure to watch the instructional video at:

www.seaeagle.jp/ja/se/cat/5-Instructions before using your Sea Eagle.