



ご質問がございましたら **SEA EAGLE, Japan**（日本正規代理店）までメールでご連絡下さい。
<https://www.seaeagle.jp/en/contact-us>

Travel Canoe 16

この度は SEA EAGLE の高品質インフレーターカヌーをお買い上げ頂き誠にありがとうございます。

組み立て・収納方法:

1. 高圧ハンドポンプのハンドルに圧力計を取り付けます。圧力計にホースを接続して下さい。
2. カヌーを広げる。バルブキャップを外して下さい。バルブステム（バルブ軸）を押しながら左へ 1/4 バルブステムが立ち上がるまで回して下さい。
3. バルブ開口部にバルブアダプターを差し込み右に回して固定して下さい。
4. ボートフロアとエアチューブを 10 PSI (69 kPa)まで膨らませてください。（順不同）
5. カヌーを膨らませ終わったら、全てのバルブキャップを閉じてください。
6. 2分割パドルは 122～152cm 調節可能です。
7. ドレインバルブ：水上ではドレインバルブ（水抜き穴）を閉じておいてください。カヌー内部に水が入った場合ドレインバルブを開ける事で水を外に排水する事が出来ます。
8. カヌーの収納：バルブキャップを取り外し、バルブステムを押しながら 1/4 右へ回すとバルブステムの弁が下がり空気が素早く出てきます。空気を抜くときは空気バルブに目や顔や物を近づけないでください。
9. バルブの方へカヌーを折り畳みながら空気を抜いてください。スケグベースを曲げないように注意してください。十分に乾燥させてから収納してください。

ご使用上の注意:

- SEA EAGLE 推奨のポンプを使用してください。市販のエアコンプレッサーは絶対に使用しないでください。（CO₂または空気）
- 現地の河川・海上航行ルール、その他、規制・規則・法律を順守しましょう。
- ボート、カヌーに乗る際は必ずライフジャケットを着用しましょう。
- 絶対に子どもだけで SEA EAGLE ボート・カヌーを使用しないでください。
- 飲酒または薬を服用した後はカヌーを操縦しないでください。操船中にアルコールを摂取しないでください。
- 砂利や岩場の上などで SEA EAGLE ボート・カヌーを引きずらないようにしてください。可能であれば持ち上げて運んで下さい。
- ボートの最大積載量、定員を超えて乗船しないでください。最大積載量はボート内側に記載しています。
- 1人でカヌー、ボーティングに行かないでください。特にキャンプ、海旅や急流下りをする場合。
- 本製品は救命具ではありません。SEA EAGLE ボート・カヌーを絶対に救命具として使用しないで下さい。
- 水上に行く時は、常に誰かに何処に誰と行くか帰宅の予定は何時になるかを伝えて下さい。
- 全ての ボート・カヌーはメーカーの欠陥に対する3年間の保証があります（詳しくはオンラインでご確認ください。）

SEA EAGLE 製品をご利用になる前に www.seaeagle.jp/ja/se/cat/5-Instructions で取扱説明ビデオをご覧ください。



Questions: Email Customer Service at <https://www.seaeagle.jp/en/contact-us>

Travel Canoe 16

Thank you for your purchase of our high quality inflatable canoe.

Basic Inflation Instructions:

1. Connect the inline pressure gauge to the handle of the High Pressure hand Pump. Connect the hose to the pressure gauge.
2. Roll out canoe. Remove valve caps. Press and turn the valve stem a $\frac{1}{4}$ turn to the left until it pops up.
3. Insert valve adapter into valve opening, turn right to lock in place.
4. Inflate the floor and both sides to 10 PSI in no particular order.
5. Close valve caps after inflating the canoe.
6. The 2-part canoe paddles are adjustable from 122~152 cm.
7. Keep drain valves closed while on the water. Can be opened to assist in draining water from the canoe when near the shore or on land.
8. Deflate canoe by removing valve caps, push stem down and turn stem a $\frac{1}{4}$ turn to the right until it stays down. Keep face away from air as it releases.
9. Fold canoe toward valves. Skeg base must be kept flat. Wipe dry before storing.

Other Points:

- Only use Sea Eagle recommended pumps and NEVER an air compressor (CO2 or air)
- Be aware of local boating rules and regulations and abide by them accordingly.
- Always wear a life jacket when on the water.
- DO NOT allow children to use Sea Eagle boats unsupervised.
- DO NOT consume alcohol while boating or operating a boat while under the influence of alcohol or drugs.
- DO NOT drag your Sea Eagle boat over rocks or gravel if it can be avoided.
- DO NOT exceed the certified maximum weight capacities of this boat – see capacity label on the inside of canoe.
- DO NOT go boating alone, especially if camping, exploring or going down a white water river.
- DO NOT use your Sea Eagle Boat as a personal flotation device as they are not designed for that use.
- Always let someone know where you are going and when you plan to return.
- All Sea Eagle boats have a limited 3 year Warranty against manufacturer's defects (more detail online)

Make sure to watch the instructional video at:

www.seaeagle.jp/ja/se/cat/5-Instructions before using your Sea Eagle.