



ご質問がございましたら SEA EAGLE, Japan（日本正規代理店）までメールでご連絡下さい。
<https://www.seaeagle.jp/en/contact-us>

Sport Kayak: SE330/SE370

この度は SEA EAGLE の高品質インフレーターカヤックをお買い上げ頂き誠にありがとうございます。

組み立て・収納方法:

1. 3パートバルブアダプターの中で一番大きいノズルのうねのある端をホースに挿入してください。
2. カヤックを広げて下さい。リングを5つのエアバルブベースにそれぞれ取り付けて、バルブベースにバルブをねじ込んで下さい。シートにもリング・バルブを同じように取り付けて下さい。
3. カヤックを膨らませ終えたら全てのバルブキャップを閉じてください。
4. パドル: シャフトの端にドロップガードを挿入し、3つの穴が中央にくるようにシャフトを組み立ててください。
5. ドレインバルブ: カヤック内部に入った水を排水するために、後部のドレインバルブを開けてください。水上ではドレインバルブは閉じておかれなければなりません。
6. カヤックの収納: バルブを緩めカヤックとシートの空気を抜いて下さい。
7. スケグにスケグ・プロテクターをつけてバルブの方へカヤックを折り畳みながら空気を抜いてください。十分に乾燥させてから収納してください。

ご使用上の注意:

- 作動圧力: エアチューブ/ ボートフロア/ Deluxe Kayak Seat (DKS)（デラックス カヤックシート）1.1 PSI (7.6 kPa)。
- SEA EAGLE 推奨のポンプを使用してください。市販のエアコンプレッサーは絶対に使用しないでください。(CO₂または空気)
- 現地の河川・海上航行ルール、その他、規制・規則・法律を順守しましょう。
- ボート、カヤックに乗る際は必ずライフジャケットを着用しましょう。
- 絶対に子どもだけで SEA EAGLE ボート・カヤックを使用しないでください。
- 飲酒または薬を服用した後はカヤックを操縦しないでください。操船中にアルコールを摂取しないでください。
- 砂利や岩場の上などで SEA EAGLE ボート・カヤックを引きずらないようにしてください。可能であれば持ち上げて運んで下さい。
- ボートの最大積載量、定員を超えて乗船しないでください。最大積載量はボート内側に記載しています。
- 1人でカヤック、ボーティングに行かないでください。特にキャンプ、海旅や急流下りをする場合。
- 本製品は救命具ではありません。SEA EAGLE ボート・カヤックを絶対に救命具として使用しないで下さい。
- 水上に行く時は、常に誰かに何処に誰と行くか帰宅の予定は何時になるかを伝えて下さい。
- 全ての ボート・カヤックはメーカーの欠陥に対する3年間の保証があります（詳しくはオンラインでご確認ください。）

SEA EAGLE 製品をご利用になる前に www.seaeagle.jp/ja/se/cat/5-Instructions で取扱説明ビデオをご覧ください。



Questions: Email Customer Service at <https://www.seaeagle.jp/en/contact-us>

Sport Kayak: SE330/SE370

Thank you for your purchase of our high quality inflatable kayak.

Basic Inflation Instructions:

1. Insert the ribbed end of the largest nozzle of the 3-part valve adapter (included with your pump) into the hose.
2. Roll out kayak. Attach the ring to the base of the 5 air valves and screw the valve in the valve base. Do the same for the seats.
3. Close valve caps after inflating.
4. Paddle assembly: Insert the drip guard on the end of the paddle shaft. Assemble shaft with the three holes in the middle.
5. Open rear drain valve to remove water from kayak. Drain valve should be kept closed when on water.
6. Deflate kayak and seats by unscrewing the valves.
7. Put on skeg protectors and fold kayak toward valves. Wipe dry before storing.

Other Points:

- Working pressure of the floor, pontoons and seats: 1.1 PSI
- Only use Sea Eagle recommended pumps and NEVER an air compressor (CO2 or air)
- Be aware of local boating rules and regulations and abide by them accordingly.
- Always wear a life jacket when on the water.
- DO NOT allow children to use Sea Eagle boats unsupervised.
- DO NOT consume alcohol while boating or operating a boat while under the influence of alcohol or drugs.
- DO NOT drag your Sea Eagle boat over rocks or gravel if it can be avoided.
- DO NOT exceed the certified maximum weight capacities of this boat – see capacity label on the inside of kayak.
- DO NOT go boating alone, especially if camping, exploring or going down a white water river.
- DO NOT use your Sea Eagle Boat as a personal flotation device as they are not designed for that use.
- Always let someone know where you are going and when you plan to return.
- All Sea Eagle boats have a limited 3 year Warranty against manufacturer's defects (more detail online)

Make sure to watch the instructional video at:

www.seaeagle.jp/ja/se/cat/5-Instructions before using your Sea Eagle.